

# Zigbee 3.0 + 2.4G Lamp Instruction Manual

## Contents

---

<u>Product feature</u> .....	2
<u>2.4G RF Remote control instruction</u> .....	3-6
<u>Link / Unlink Instructions</u> .....	3
<u>Compatible with remote</u> .....	4
<u>Dynamic mode table selection</u> .....	5
<u>Auto transmitting &amp; Modes synchronization</u> .....	6
<u>“Do Not Disturb” mode is activated and shut down</u> .....	6
<u>DMX512 Transmitter control instruction</u> .....	7
<u>Smartphone APP control instruction</u> .....	8
<u>Philips Hue control instruction</u> .....	9
<u>Alexa voice control instruction</u> .....	10
<u>Google Home voice control instruction</u> .....	11
<u>Attention</u> .....	12

## Product feature

Made by new Zigbee 3.0 wireless transmitting technology with low power consumption, strong ability to build network automatically and anti-interference. with MiBoxer Zigbee gateway to get wireless dimming color, remote control, timing control, group control, music rhythm function. Support 2.4G RF remote control.



Follow Zigbee 3.0 standard protocol



Support Zigbee 3.0 remote control(Zigbee 3.0 gateway is needed)



Support 2.4G Remote control



Auto transmitting & Modes auto synchronization



Support Smartphone app control(Zigbee 3.0 gateway is needed)



Support third party voice control(Zigbee 3.0 gateway is needed)

## Various control solution:



Philips  
Hue



MiBoxer  
Zigbee Gateway



IKEA  
TRÅDFRI



2.4GHz  
Remote




Amazon  
Echo Plus



## 2.4G RF Remote control instruction


### 1). Linking Code Instructions



Power off and power on again after 10 seconds.



Short press " | " button 3 times within 3 seconds when light on.




Lights blink 3 times slowly means linking is done successfully.




Linking failed if light is not blinking slowly, Please follow above steps again. (Note: Light that have linked can't link again)


### 2). Unlinking Code Instructions



Power off and power on again after 10 seconds.



Short press " | " button 5 times within 3 seconds when light on.



Lights blink 10 times quickly means unlinking is done successfully.



Unlinking failed if light is not blinking quickly, Please follow above steps again. (Note: Light haven't linked that don't need to unlink)

### 3). Compatible with these 2.4G RF remote controls (Purchased separately)




FUT100




FUT089S



FUT089  
FUT089-B



FUT088




FUT092  
FUT092-B




FUT096  
FUT096-B



B8



B0 / B0-B




B3 / B3-B / T3



B4 / B4-B / T4



S2-B / S2-W  
S2-G



FUTD01

#### 4). Dynamic mode table selection (Only for 2.4G RF remote control)

**Select dynamic mode table 1:** While the light is in static mode, short press “**S+**” button 5 times quickly until blue light flashes 3 times slowly, static mode is activated successfully.

**Select dynamic mode table 2:** While the light is in static mode, short press “**S-**” button 5 times quickly until yellow light flashes 3 times slowly, static mode is activated successfully.

#### Dynamic mode table 1 (default)

Number	Dynamic Mode	Brightness / Saturation / Speed
1	Mardi Gras	Adjustable
2	Automatic color change	
3	Sam	
4	Gemstone	
5	Twilight	
6	American	
7	Fat Tuesday	
8	Party	
9	Slow Color Splash	

#### Dynamic mode table 2 (need to switch manually)


Number	Dynamic Mode	Brightness / Saturation / Speed
1	Seven colors gradual change	Adjustable
2	White light gradual change	
3	RGB gradual change	
4	Seven colors jump to change	
5	Jump to change randomly	
6	Red light gradual change + Flash 3 times	
7	Green light gradual change + Flash 3 times	
8	Blue light gradual change + Flash 3 times	
9	White light gradual change + Flash 3 times	


## 5). Auto transmitting (2.4G RF remote signal)

The light can transmit remote signal to another light automatically while the distance between lights are 30m, the remote control distance is unlimited. (Attention: all lights must be linked with same remote)

## 6). Modes auto synchronization (2.4G RF remote control)

Different lights can work synchronously when they are started at different times, light by the same remote, under same dynamic mode and within 30m distance.

 The same dynamic mode, the same speed can be synchronized.



## 7). “Do Not Disturb” is activated and shut down (default activated)

Turn on “Do Not Disturb” (wide using in the area which have power failure frequently to save energy)

### 2.4G RF Remote turn on and turn off instruction

#### Turn on “Do Not Disturb”:

Press “OFF” button three times within three seconds and press “ON” button three times, Activated successfully once led light flashes four times quickly.

**Attention:** Do not disturb mode is activated

1. When the light is OFF status (For example: Use app or remote to turn off light)

The light is OFF status once you turn off power and turn on again. **(User must turn off and turn on power twice times to activate light or use APP / remote to activate light)**

2. When the light is ON status

The light is ON status once you turn off and turn on power one time.

#### Turn off “Do Not Disturb”:

Press “ON” button three times within three seconds and press “OFF” button three times, closed successfully once led light flashes four times slowly.

**Attention:** The light will be always “ON” status if you turn on and turn off power once user closed “Do Not Disturb” mode.

App turn on and off “Do Not Disturb” mode instruction ([check details in page 8](#))

# DMX512 LED Transmitter control instruction

Only for RGB+CCT light, Support DMX512 LED Transmitter control (Purchase separately)

- ① Choose the zone for the light by pressing “+” or “-” (e.g. “CH12” means zone 12)



## Link

Power off and power on again after 10 seconds.

When the light is on, short press “**SET**” 3 times within 3 seconds

The light blink slowly 3 times, means the linking is done successfully

## Unlink

Power off and power on again after 10 seconds.


When the light is on, short press “**SET**” 5 times within 3 seconds

The light blink quickly 10 times, means the unlinking is done successfully



If the link or unlink failed, please follow the above steps again.


## DMX512 LED Transmitter Connection Diagram



## Smartphone APP control instruction


Added Zigbee 3.0 gateway into “TUYA Smart” App (please review instruction of Zigbee 3.0 gateway)

- 1). Connect with power supply.
- 2). Pairing network (**attention: factory default is pairing network**).  
Way: turn off and turn on light 3 times or over 3 times continuously, the light is in breathing status.
- 3). Open “TUYA Smart” APP to click Zigbee gateway, then click “Add sub device”.
- 4). Click “Indicator is flashing quickly”.
- 5). Support APP dimming or group control and etc once added successfully.



## App turn on and off “Do Not Disturb” mode (default activated)

Click the light which need to be set up or group control --- click “More” --- click “Power-on behavior” --- turn on or off









# Philips Hue control instruction

## Added "Philips Hue" into APP

- 1). Connect with power supply
- 2). Pairing network (**attention: factory default is pairing network**)  
Way: turn off and turn on light 3 times or over 3 times continuously, the light is in breathing status.
- 3). Open "Philips Hue" App to click "SETTINGS" and click "Lights"
- 4). Click "+" on the top of right corner
- 5). Click "Search"
- 6). Click "Start configuration", Follow the app instruction to complete configuration



# Alexa voice control instruction

## 1). Alexa control (Audio support Zigbee 3.0 protocol)

You can connect directly if your Amazon ECHO already is built-in zigbee 3.0 protocol, following model with zigbee 3.0 protocol:

Amazon ECHO Plus ( 2nd Gen), ECHO (4th Gen), ECHO Studio, ECHO Show (2. Gen)

- 1). Connect with power supply
- 2). Pairing network (**attention: factory default is pairing network**)

Way: turn off and turn on light 3 times or over 3 times continuously, the light is in breathing status.

"Alexa, Discover devices"




- 3). Say to Amazon ECHO "Alexa, Discover devices"  
Wait for a while to discover device, Voice control is activated

## 2). Alexa control (Audio don't support Zigbee 3.0 protocol)

Please add device into Miboxer Zigbee 3.0 gateway if your Alexa don't support zigbee 3.0 protocol ([check details in page 8](#)), then start following steps


- 1). Open Alexa App
- 2). Click "More" on the bottom of right corner
- 3). Click "Skills & Games"



- 4). Click "Q" on the top of right corner
- 5). Type into "Smart life" and search




- 6). Click "Smart Life" skill, follow instruction to finish configuration and start voice control




# Google Home voice control instruction

Please add device into MiBoxer Zigbee 3.0 gateway ([check details in page 8](#)) and start following steps


- 1). Open Google Home App
- 2). Click “+” on the top of left corner




- 3). Click “Set up device”



- 4). Click “Works with Google”



- 5). Click “Q” on the top of right corner
- 6). Type into “Smart life” and search
- 7). Click “Smart Life” skill, follow instruction to finish configuration and start voice control



## Attention

1. Please turn off power supply before installation.
2. Please ensure input voltage to be same as requirements from device.
3. Don't disassemble device if you are not expert, otherwise it will damage it.
4. Please do not use the light in the place with widely range metal area or strong electromagnetic wave nearby, otherwise, the remote distance will be seriously affected.



Scan QR code to watch Zigbee series video instruction

Or enter into following link directly

<https://miboxer.com/light/video/zigbee.html>



Made in China